

ROMAN TUB (DECK) DIVERTER VALVE
W/ INTEGRAL VACUUM BREAKER
INSTRUCTION SHEET

It is recommended that only licensed plumbers with knowledge of installing decorative products be employed to install Legacy Brass products.

INSTALLER NOTICE: Do not use plumbers' putty to install this product. The use of plumbers' putty will void the homeowner's finish warranty. We recommend using a clear silicone sealant and teflon tape around threaded parts.

VERY IMPORTANT !! Prior to installing the valves, it is critical that the supply lines be completely flushed of all debris and dirt.

- 1) THIS DIVERTER VALVE REQUIRES A 1 3/8" DIAMETER HOLE. The "Hot" and "Cold" valves require a 1 1/4" diameter hole.
 - 2) Unscrew the top nut from the valve body.
 - 3) Insert the valve from underneath the deck and screw the top nut back on.
 - 4) Tighten the valve to the deck using the bottom nut on the valve.
- **NOTE: THIS VALVE ACCEPTS BOTH THREADED OR SWEAT CONNECTIONS. (IF SWEATING THE CONNECTIONS, REMOVE THE DIVERTER CARTRIDGE AS A PRECAUTION).**
- 5) Affix a 3/4" x 3/4" x 3/4" tee (NOT Provided) to the bottom inlet of the valve.
 - 6) Connect the "Hot" and "Cold" lines to the bottom tee.
 - 7) Connect the 24" high pressure (stainless steel braided) hose, which is provided, to the 1/2" outlet.
 - 8) Connect 3/4" line to the 3/4" outlet and run to the spout nipple.
 - 9) The stem and all-thread on the diverter valve will need to be cut to size to accommodate the trim (handle and escutcheon). Allow a 1/2" of the stem to project above the all-thread.

****SEE THE REGULAR ROMAN TUB INSTRUCTION SHEET FOR ALL OTHER INSTRUCTIONS.**

